

JetVue Installation Tips:

Prior to installation of printed graphics, we recommend attaching a small piece of CLEAR FOCUS film to glass as a test to help you become accustomed to the film's characteristics, including adhesion strength.

- Glass surface must be clean. Use mild soap and water to clean the glass. Do not use glass cleaners with solvents (e.g., Windex®).
- Surface must be completely dry. Use lint-free cloth or industrial paper towels to dry glass.
- Temperature of glass must be moderate between approx. 40° F (5° C) and 90° F (32° C).
- In cold weather, apply film in late afternoon, after windows have warmed up, or, in the case of a vehicle, in a garage or other enclosed area (with the vehicle engine turned off). Applying film to glass that is too cold may adversely affect adhesion of film.
- In hot weather, apply film in the early morning, while glass is still cool. Applying film to glass that is too hot can cause the film to stretch during installation.